

Removal and Cleaning of Your Powerhead

- 1) Slide the powerhead from the CY192 protein skimmer tube.
- 2) Remove the powerhead cover by inserting a flat-head screwdriver at slot (C) and gently prying.
- 3) Remove the round plate (B) by lining up the flat portion to the locking guide.
- 4) Wash all parts under running tap water. Never use a detergent on parts which will come into contact with aquarium water. Make sure air lines and elbows (A) are clear of any foreign matter.
- 5) Reassemble the powerhead and place it back on the protein skimmer tube.
- 6) The powerhead should be regularly cleaned, at least once a month, and should be replaced every twelve to eighteen months for optimal efficiency of the protein skimmer.

MUFFLER

The CY192 works better without the muffler (E). If the noise level is acceptable without the muffler, remove it. To clean the muffler, soak it in warm water and allow it to dry completely. It can also be replaced with a coarse airstone, which allows more air in than the standard muffler but has quieter operation.

